

# Enclosure Unload Instructions

**1** Tow truck backs up tail to tail with delivery truck



**2** Tie winch around front of the pallet to pull pallet onto the flatbed truck



**3** Tilt bed and drive slowly away to place pallet on ground



**Warning – Tow truck bed should be at least as long as pallet to prevent damage. Pallet dimensions will be provided prior to delivery**